

SPARE PARTS LIST

SPARE PARTS LIST ECO VACUUM					
No. Part	Code Part	Description	Validity start date	Validity end date	Notes
1	1602490	CONTROLS STICKER ECO VACUUM	04/01/1900	31/12/2099	
2	1602633	COMMAND BOARD OR-100	04/01/1900	31/12/2099	
3	1602611	POWER BOARD PL082_0 230V	04/01/1900	31/12/2099	230V
4	1601819	VACUUM PUMP EPV30 230V/50HZ MA-VIB	04/01/1900	31/12/2099	230V
5	1604002	SILICONE RUBBER (2 PCS) MAE	04/01/1900	31/12/2099	
6	1603686	FLAT SEALING WIRE 3X0.1 (1 MT)	04/01/1900	31/12/2099	
7	1604345	BLACK TEFLON BAND 22MM (1 MT)	04/01/1900	31/12/2099	
8	1604003	"T" SILICONE RUBBER L=314MM	04/01/1900	31/12/2099	
9	1604409	D=6X9 HOSE (5 MT)	04/01/1900	31/12/2099	
10	1604408	D=4X6 HOSE (5 MT)	04/01/1900	31/12/2099	
11	1604082	VACUUM SENSOR SIGNAL LUX 693MBAR	04/01/1900	31/12/2099	
12	1602474	"PUSH" STICKER ECO VACUUM	04/01/1900	31/12/2099	
13	1601815	VACUUM PUMP EXHAUST FILTER CP30/EVP30	04/01/1900	31/12/2099	
14	1604048	POWER CABLE 3X1X2300 SHUKO EUR	04/01/1900	31/12/2099	230V
15	1602707	FULL WHITE DOOR ECO VACUUM	02/01/1900	31/12/2099	
16	1602705	COMPLETE WHITE SHELL ECO VACUUM	04/01/1900	31/12/2099	

SPARE PARTS LIST

